



WWW.SMITTYBILT.COM

**Installation Instructions**  
**MAG Armor**  
**Part#76992 & 76994**  
**2007-2017 Wrangler 2&4 door**

NOTE: Carefully read entire instructions thoroughly before attempting to install this part.

Parts included	Qty
Front fender panel	L&R
Front door panel	L&R
Rear door panel (4DR only)	L&R
Rear quarter panel	L&R
Driverside bottom rear quarter panel	1
Front rocker panel	L&R
Rear rocker panel (4DR only)	L&R
B-pillar (4DR only)	L&R

\*\*Actual design may vary from photo. Install remains the same.  
**\*\* ONLY INSTALL ON CLEAN VEHICLE TO AVOID PAINT DAMAGE.\*\***  
**Failure to follow instructions may result in vehicle or armor panel damage.\*\***

4 door includes 15 pcs  
2 door includes 9 pcs  
Micro fiber rag included.



**\*Due to factory variations the Trail Rated badge or other badges may need to be re-located.**  
**\*Do not leave on your vehicle, remove panels daily.**  
**\*Do not use when surface temperatures exceed 130 degrees Fahrenheit**



[WWW.SMITTYBILT.COM](http://WWW.SMITTYBILT.COM)

**Installation Instructions**  
**MAG Armor**  
**Part#76992 & 76994**  
**2007-2017 Wrangler 2&4 door**

**Prepare MAG armor.**

- Un pack all MAG armor. Lay out all pieces on a clean soft surface, a moving blanket works well to protect armor from damage. Do not stack pieces. This will allow pieces to unroll. Placing armor in direct sunlight or heated room will help them flatten faster.
- Use only a soft cloth or micro fiber cloth. Clean MAG armor with a mild detergent on both surfaces. Dry completely. Avoid scrubbing the outer surface as damage may occur. You may use a quick detail spray to ensure a smooth clean surface. Transparent quick detailers work the best. Do NOT use any wax that requires the use of buffing to remove filler compounds. Nano wax, Lucas Slick Mist, and Turtle wax ICE spray detailers work well.

**Prepare vehicle surface.**

- Before applying to vehicle be sure surface is clean and dry. Do not apply to surfaces that have an uncured coating such as paints, clear coats, wraps , decals or waxes. Any contaminants on vehicle surface will damage paint if MAG armor is installed over contaminants.

**Applying MAG armor**

- Make sure entire MAG armor panel is flat against the vehicle. Ensure there are no air pockets or hardware preventing entire from being flat against vehicle.
- When installing the first time, you may need to hold panel on vehicle till it adheres evenly due to being rolled up for an extended period of time.
- If you need to reposition armor, you must remove it completely. DO NOT pull on armor to reposition, damage to paint and/ or armor may occur.
- You may find it easier to install by lining up a corner or door handle cutout and then ease the rest of the armor panel on.
- Do not use over non-metallic body fillers, simulated finishes, or uncured re-painted surfaces.

**Storage.**      **(KEEP PACKAGING TUBE TO USE FOR STORAGE)**

- Store in a clean, dry place.
- Stack flat panels on a level surface. DO NOT stack with magnetic surface facing each other, then carefully roll up and put back into storage tube.
- When rolling, make sure no panels fold or crease, this will cause damage to panels.
- Keep tube in upright position to prevent flat spots. Roll armor panels with printed side facing out.
- Use a piece of tissue paper between panels to avoid scratches.

For Technical Support/Warranty Information please call 310-762-9944 Smittybilt, 400 W. Artesia Blvd Compton, CA 90220



WWW.SMITTYBILT.COM

# Installation Instructions

## MAG Armor

### Part#76992 & 76994

### 2007-2017 Wrangler 2&4 door



### Warning

- MAG armor and vehicle should be clean and dry before applying armor panels. DO NOT rub dry, allow to air dry if possible.
- Moisture and dirt will collect between armor panel and vehicle. Remove and clean MAG armor and vehicle routinely and after off-road travel or exposure to harsh conditions.
- To prevent damage to vehicle it is recommended to remove armor daily.
- Long term application of armor panel on vehicles exposed to sunlight can result in uneven fading of vehicle surface. This happens because the armored surface is not exposed to UV rays which cause paint fading.
- Clean only with a soft cloth and mild detergent. Avoid scrubbing and buffing as this will damage the armor's top layer. Treat armor panels as you would the finish of your vehicle.
- Do not use panels below 32°F. panels will become brittle and may be damaged when installing or removing panels. Cold weather use is not recommended.
- Failure to follow use and care instructions may cause damage to armor panels or vehicle surface. Smittybilt will not be held liable for and damages caused by misuse, abuse or failure to follow instructions and warnings.



- Magnets or other magnetic devices keep sufficient distance from magnets.
- Warn others to keep away from magnetic storage media
- Keep away from magnetic storage media
- Do not ingest immediately seek medical attention.

For Technical Support/Warranty Information please call 310-762-9944 Smittybilt, 400 W. Artesia Blvd Compton, CA 90220