Owner's Manual



Automatic Valve Stem Tire Deflators Instruction Manual Part # S/B2923



Introduction

Thank you for choosing Smittybilt accessories for your off-roading needs! If you would like to view our full range of available accessories, please visit us at www.smittybilt.com







Overland Chairs

Overland Tents

Trail Bag

Important Notes Before Starting



IMPORTANT NOTE

Carefully read through this entire instruction manual thoroughly before attempting to operate these tire deflators.

Specifications





Specification	2923 - Tire Deflators
Pressure Range	10-30 PSI (0.7-2.0 Bar)
Internal Material	Stainless-Steel
External Material	Powder-Coated Nickel-Plated
Features	Automatic Stop
	Laser-etched gauge for accurate deflation
	Quickly air down all four tires at once
	PSI and Bar Markings
	 Neoprene Carrying Pouch



For Technical Support / Warranty Information please call 800-776-0767 Smittybilt, 1017 W 600 N STE 4, Ogden, UT 84404

Operating Instructions



Step 1:

When ready to use the deflators, remove them from the carrying pouch. Unscrew the top half from the bottom half until the bottom half lines up with the arrows for your desired tire pressure. Then screw down the gold ring until it sits snugly against the bottom half. Do this for all 4 deflators

Note: The photos on the left are set to 10 PSI.



Step 2:

Screw all 4 deflators onto each tire. The deflators will automatically begin deflating the tire to the set PSI.



Step 3:

Once the tires reach the set PSI, the deflators will stop releasing air. Once done, the deflators can be removed and stored back in the pouch for future use.

Note: to preserve the longevity of the internal spring it is recommended to set them to below 15 PSI when not in use.



For Technical Support / Warranty Information please call 800-776-0767 Smittybilt, 1017 W 600 N STE 4, Ogden, UT 84404

Warranty

SMITTYBILT ADVANTAGE WARRANTY

LIMITED 1-YEAR WARRANTY

Smittybilt Automotive Products, LLC (SAP) warrants to the original purchaser that (a) the physical components (e.g., outer shell, display, handles, etc.) of any SAP **Tire Deflators** will be free of defects in material and workmanship for 1-year from the date of purchase of the tire deflators. This warranty applies only to the original purchaser of the tire deflators and is non-transferable. To obtain any warranty service, you must provide SAP with a proof of purchase and date of purchase that is acceptable to SAP, such as a copy of your purchase receipt.

This warranty does not cover labor of part replacement of the tire deflators. SAP will, at its sole discretion, provide replacement part(s) for a defective tire deflator or component, provided this is done within the warranty period. To request assistance under warranty, one must call or email using the phone number or email at the bottom of this page. This warranty does not apply (1) to finish or paint; (2) if the tire deflators have been damaged by accident, abuse, misuse, collision, modification, misapplication, improper installation, changes to the factory set parameters, or improper service; or (3) any normally wearable part. This warranty is void if any SAP serial number has been removed or defaced; or if the tire deflators are used for any commercial, industrial, or rental applications. This warranty only applies to tire deflators bought, sold, and used within the Untied States or Canada unless otherwise specifically agreed in writing by SAP.

THE WARRANTY SET FOURTH ABOVE IS THE ONLY WARRANTY. THERE ARE NO OTHER WARRANTIES, EXPRESSED OR IMPLIED, INCLUDING BUT NOT LIMITED TO IMPLIED WAR-RANTIES OF MERCHANT ABILITY OR FITNESS FOR A PARTICULAR PURPOSE. ANY IM-PLIED WARRANTY WHICH BY LAW MAY NOT BE EXCLUDED IS LIMITED TO A DURATION OF ONE (1) YEAR FROM THE DATE OF ORIGINAL RETAIL PURCHASE OF THE PRODUCT. No SAP dealer, agent, or employee is authorized to make any modification, extension or addition to this warranty. SAP SHALL NOT BE LIABLE FOR SPECIAL, INDIRECT, INCIDENTAL OR CONSE-QUENTIAL DAMAGES (INCLUDING, BUT NOT LIMITED TO, LOST PROFITS, DOWN TIME OR LOSS OF USE) UNDER ANY LEGAL THEORY, EVEN IF SAP WAS ADVISED OF THE POSSIBIL-ITY OF SUCH DAMAGES. Some states do not allow the exclusion of implied warranties or the exclusion or limitation of liability for incidental or consequential damages, or limitations on how long an implied warranty lasts, so the above limitation or exclusion may not apply to you. This Warranty gives you specific legal rights. You may also have other rights that vary from state to state. SAP reserves the right to change product design without notice. In situations in which SAP has changed a product design, SAP shall have no obligation to upgrade or otherwise modify previously manufactured products. For warranty inquires contact SAP at:

Smittybilt Automotive Products, LLC
Customer Service Department
Call 1-800-776-0767 or Email info@smittybilt.com





For Technical Support / Warranty Information please call 800-776-0767 Smittybilt, 1017 W 600 N STE 4, Ogden, UT 84404