



**Overland Camp Light & Overland Camp Light Pro  
Owner's Manual  
Part # S/B2952 & S/B2953**



## Introduction

Thank you for choosing Smittybilt accessories for your overlanding needs! If you would like to view our full range of available accessories, please visit us at [www.smittybilt.com](http://www.smittybilt.com)



Overland Chairs



Overland Tents



Trail Bag

## Important Notes Before Starting



### IMPORTANT NOTE

Carefully read through this entire instruction manual thoroughly before attempting to operate this light.



### WARNING

- **HEAT WARNING - THIS ITEM GETS HOT! USE WITH CAUTION TO AVOID BURNS OR FIRE!**
- **WARNING - KEEP THIS PRODUCT AWAY FROM CHILDREN! PRODUCT CAN GET HOT!**
- **WARNING - DUE TO THEIR SMALL SIZE BATTERIES CAN BE EASILY SWALLOWED BY CHILDREN. KEEP AWAY FROM CHILDREN.**
- **LIGHTNING STRIKE HAZARD WARNING - DO NOT USE DURING A THUNDERSTORM. BEFORE A THUNDERSTORE APPROACHES ENSURE THE OVERLAND CAMP LIGHT IS STORED SAFELY. IF YOU ARE CAUGHT OUTSIDE DURING A THUNDERSTORM DO NOT STAND NEAR THIS OVERLAND CAMP LIGHT. STAY A SAFE DISTANCE AWAY FROM THE LIGHT AS IT CAN UNINTENTIONALLY ACT AS A LIGHTNING ROD. FAILURE TO FOLLOW THESE PRECAUTIONS CAN RESULT IN SERIOUS PERSONALLY INJURY OR DEATH!**
- **LED SAFETY WARNING - THIS PRODUCT CONTAINS HIGH INTENSITY LEDs. TO PREVENT TEMPORARY OR PERMANENT EYE DAMAGE, DO NOT STARE INTO THE LIGHT BEAM AT ANY DISTANCE.**
- **RISK OF ELECTRICAL FIRE - ONLY USE THE INCLUDED CHARGER TO CHARGE THIS OVERLAND CAMP LIGHT. FAILURE TO DO SO MAY RESULT IN PROPERTY DAMAGE, PERSONAL INJURY, OR EVEN DEATH.**
- **READ AND FOLLOW ALL WARNINGS PRINTED IN THIS GUIDE PRIOR TO USE.**



For Technical Support / Warranty Information please call 800-776-0767  
Smittybilt, 1017 W 600 N STE 4, Ogden, UT 84404

# Technical Information

## Overland Camp Light Pro Box Contents




Travel Bag

Wireless Remote



USB Charging Block

USB-C Charging Cable



Tech Data	Overland Camp Light Pro
Lumens	High: 1200 Max True-Lumens Spotlight: 400 Max True-Lumens
Runtime	Low Flood: 10 Hours* / High Flood: 1.5 Hours* Spotlight: 4.5 Hours*
Battery	Type: 21700 Lithium Ion Total Capacity: 4,000mAh Voltage: 3.7V
IP Rating	IP54
Impact Resistance	1 Meter
Connector Type	USB-C
Extended Dimensions	96" x 13.5" x 13.5"
Collapsed Dimensions	24" x 2.75" x 2.75"
Materials	Aluminum / ABS Plastic / Fiberglass
Features	<ul style="list-style-type: none"> <li>• Built-In Flashlight</li> <li>• USB-C Rechargeable</li> <li>• Wireless Remote</li> <li>• Dimmable LEDs</li> <li>• Red Light Mode</li> <li>• 1-Year Warranty</li> </ul>

\* Battery Runtime is approximate



For Technical Support / Warranty Information please call 800-776-0767  
Smittybilt, 1017 W 600 N STE 4, Ogden, UT 84404

# Technical Information

## Overland Camp Light Pro Box Contents




Travel Bag

Wireless Remote



USB Charging Block

USB-C Charging Cable



360° Flood LED

Fiberglass Telescoping Pole

- Collapsible to 25.5"

- Min Height: 2.1' (25.5")

- Max Height: 10' (120")

Lock Ring

Battery Pack

USB-C & USB A charging ports for other devices.

Magnetic wireless remote storage

Tripod Leg

Rubber feet for grip

Hole for stakes

Tech Data	Overland Camp Light Pro
Lumens	High: 2600 Max True-Lumens Low: 150 True-Lumens
Runtime	High: 6 Hours* Low: 72 Hours*
Battery	Type: 7x 18650 Total Capacity: 14,000mAh Voltage: 3.7V
IP Rating	IP54
Impact Resistance	1 Meter
Connector Type	USB-A & USB-C
Extended Dimensions	120" x 24" x 27"
Collapsed Dimensions	25.5" x 3" x 3"
Materials	Aluminum / ABS Plastic / Fiberglass
Features	<ul style="list-style-type: none"> <li>Built-In Power Bank</li> <li>USB-C Rechargeable</li> <li>Wireless Remote</li> <li>Dimmable LEDs</li> <li>Red Light Mode</li> <li>1-Year Warranty</li> </ul>

\* Battery Runtime is approximate



For Technical Support / Warranty Information please call 800-776-0767  
Smittybilt, 1017 W 600 N STE 4, Ogden, UT 84404

# 2952 - Overland Camp Light

## Getting Started:

Follow the label on the flashlight to plug in the battery.

## Power/Mode Button:

- Press once to turn on
- Press to cycle through modes:
  1. Spotlight
  2. Flood Light
  3. Red Flood Light
  4. Flashing Red Flood Light
  5. Flashing Flood Light
  6. Off
- After 5 Seconds of no mode change, the next press will turn the light off.

## Change Brightness:


- Press and Hold to increase or decrease the brightness
- The light will blink 3 times to indicate minimum or maximum brightness level.

## Mode Recall:

The Smittybilt Overland Camp Light remembers the last used light mode. When the light is off, turning it back on will return to the last used mode.

## Wireless Remote:


- Wireless remote works from up to 15' away.
- Able to control light modes and brightness
- The remote can be magnetically attached to the base of the tripod when not in use.
- Note: After the light has remained off for 8 or more hours, you will have to turn the light on using the power button before the remote can be used again.



## FCC Notice:

FCC ID# 2A85RFLIPRO - This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with these instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If the equipment causes interference to radio or television reception, which can be determined by turning the equipment off and on, users are encouraged to try to correct the interference by using one or more of the following measures: Reorient or relocate the receiving antenna. Increase the separation between the equipment and receiver. Connect the equipment into an outlet on a circuit different from that to which the receiver is connected. Consult the dealer or an experienced radio/TV technician for help.


## Flashlight Features:



## Battery Level Indicator:

The power button will function as a battery level indicator when the light is turned on or off.

- 100-60% - Green
- 59-25% - Yellow
- 24-10% - Red
- 9-0% - Flashing Red



## Charging:

1. Remove the USB-C port cover
2. Plug the USB-C connector into the USB-C port on the Overland Camp Light.
3. Plug the other end of the cord into a USB charging device.

Chargers should not exceed 3A.

The battery level indicator light will blink while charging and will glow steadily when fully charged.

## Replaceable Battery:

As with all batteries, over time battery degradation will occur. To replace a dead battery. Unscrew the handle, carefully unplug the battery and replace with a 4000mAh 21700 Lithium-Ion battery with JST connector, connect the battery and screw the handle back on. Dispose of batteries responsibly.



For Technical Support / Warranty Information please call 800-776-0767  
Smittybilt, 1017 W 600 N STE 4, Ogden, UT 84404

# 2953 - Overland Camp Light Pro

## Power/Mode Button:

- Press once to turn on
- Press to cycle through modes:
  1. Spotlight
  2. Flood Light
  3. Red Flood Light
  4. Flashing Red Flood Light
  5. Flashing Flood Light
  6. Off
- After 5 Seconds of no mode change, the next press will turn the light off.

## Change Brightness:


- Press and Hold to increase or decrease the brightness
- The light will blink 3 times to indicate minimum or maximum brightness level.

## Mode Recall:

The Smittybilt Overland Camp Light remembers the last used light mode. When the light is off, turning it back on will return to the last used mode.

## Wireless Remote:

- Wireless remote works from up to 15' away.
- Able to control light modes and brightness
- The remote can be magnetically attached to the base of the tripod when not in use.
- Note: After the light has remained off for 8 or more hours, you will have to turn the light on using the power button before the remote can be used again.



## FCC Notice:

FCC ID# 2AB5RFLIPRO - This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with these instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If the equipment causes interference to radio or television reception, which can be determined by turning the equipment off and on, users are encouraged to try to correct the interference by using one or more of the following measures: Reorient or relocate the receiving antenna. Increase the separation between the equipment and receiver. Connect the equipment into an outlet on a circuit different from that to which the receiver is connected. Consult the dealer or an experienced radio/TV technician for help.

## Power Bank:

You can use the Smittybilt Overland Camp Light Pro to charge other devices via the USB-A port

## USB Port:

Output Voltage: 5V

Output Amps: 2A

## Battery Level Indicator:

The lights around the power button will function as a battery level indicator when the light is turned on or off.

- 100-76% - 4 Lights
- 75-51% - 3 Lights
- 50-26% - 2 Lights
- 25-0% - 1 Light

## Charging:

1. Remove the USB port cover
2. Plug the USB-C connector into the USB-C port on the Overland Camp Light.
3. Plug the other end of the cord into a USB charging device.

Chargers should not exceed 3A. 0-100% charge time is approximately 7 hours with a 3A charger.

The battery level indicator light will blink while charging and will glow steadily when fully charged.

## Opening the Tripod:

1. Loosen the lock ring on the body of the tripod. Do not completely unscrew the ring, just a couple of rotations is all that's needed.
2. Pull the tripod legs away from the body.
3. Articulate the legs into the open position. All three legs will move together and the lock ring body will slide down the main body.
4. When the tripod legs are fully extended, tighten the lock ring to hold the tripod in the open position.



For Technical Support / Warranty Information please call 800-776-0767  
Smittybilt, 1017 W 600 N STE 4, Ogden, UT 84404

## Extending the Camp Light and Camp Light Pro



### Step 1:

Begin by deploying the tripod of the **Camp Light** or **Camp Light Pro**.



### Step 2:

Starting at the top, pull upwards section by section. Each section will friction fit into the lower section. It may take some pulling force to get the sections to lock together.



### Step 3:

Once all the sections are fully extended, the light is ready to use.



For Technical Support / Warranty Information please call 800-776-0767  
Smittybilt, 1017 W 600 N STE 4, Ogden, UT 84404

# Warranty

## SMITTYBILT ADVANTAGE WARRANTY

### LIMITED 1-YEAR WARRANTY

Smittybilt Automotive Products, LLC (SAP) warrants to the original purchaser that (a) the physical components (e.g., outer shell, display, handles, etc.) of any SAP **Overland Camp Light or Overland Camp Light Pro** will be free of defects in material and workmanship for 1-year from the date of purchase of the light. This warranty applies only to the original purchaser of the light and is non-transferable. To obtain any warranty service, you must provide SAP with a proof of purchase and date of purchase that is acceptable to SAP, such as a copy of your purchase receipt.

This warranty does not cover labor of part replacement of the light. SAP will, at its sole discretion, provide replacement part(s) for a defective light or component, provided this is done within the warranty period. To request assistance under warranty, one must call or email using the phone number or email at the bottom of this page. This warranty does not apply (1) to finish or paint; (2) if the light has been damaged by accident, abuse, misuse, collision, modification, misapplication, improper installation, changes to the factory set parameters, or improper service; or (3) any normally wearable part. This warranty is void if any SAP serial number has been removed or defaced; or if the light is used for any commercial, industrial, or rental applications. This warranty only applies to lights bought, sold, and used within the United States or Canada unless otherwise specifically agreed in writing by SAP.

THE WARRANTY SET FORTH ABOVE IS THE ONLY WARRANTY. THERE ARE NO OTHER WARRANTIES, EXPRESSED OR IMPLIED, INCLUDING BUT NOT LIMITED TO IMPLIED WARRANTIES OF MERCHANT ABILITY OR FITNESS FOR A PARTICULAR PURPOSE. ANY IMPLIED WARRANTY WHICH BY LAW MAY NOT BE EXCLUDED IS LIMITED TO A DURATION OF ONE (1) YEAR FROM THE DATE OF ORIGINAL RETAIL PURCHASE OF THE PRODUCT. No SAP dealer, agent, or employee is authorized to make any modification, extension or addition to this warranty. SAP SHALL NOT BE LIABLE FOR SPECIAL, INDIRECT, INCIDENTAL OR CONSEQUENTIAL DAMAGES (INCLUDING, BUT NOT LIMITED TO, LOST PROFITS, DOWN TIME OR LOSS OF USE) UNDER ANY LEGAL THEORY, EVEN IF SAP WAS ADVISED OF THE POSSIBILITY OF SUCH DAMAGES. Some states do not allow the exclusion of implied warranties or the exclusion or limitation of liability for incidental or consequential damages, or limitations on how long an implied warranty lasts, so the above limitation or exclusion may not apply to you. This Warranty gives you specific legal rights. You may also have other rights that vary from state to state. SAP reserves the right to change product design without notice. In situations in which SAP has changed a product design, SAP shall have no obligation to upgrade or otherwise modify previously manufactured products. For warranty inquiries contact SAP at:

Smittybilt Automotive Products, LLC  
Customer Service Department  
Call 1-800-776-0767 or Email [info@smittybilt.com](mailto:info@smittybilt.com)



**WARNING: Cancer and Reproductive Harm**  
[www.P65Warnings.ca.gov](http://www.P65Warnings.ca.gov)



For Technical Support / Warranty Information please call 800-776-0767  
Smittybilt, 1017 W 600 N STE 4, Ogden, UT 84404