

Installation Instructions



2020+ Jeep Gladiator® JT Angular Drop Steps S/BEXJ194T-TX



For Technical Support / Warranty Information please call 1-800-776-0767
Smittybilt, 1017 W. 600 N. STE 4, Ogden, UT 84404

Introduction

Thank you for choosing Smittybilt accessories for your Jeep Gladiator®. If you would like to view our full range of available accessories, please visit us at www.smittybilt.com



Jeep JK/JL/JT® Atlas Front Bumper



Fridges



Recovery Gear and Winches

Jeep®, Gladiator®, and JT® are registered trademarks of Stellantis N.V.®

Important Notes Before Starting

! IMPORTANT NOTE

Carefully read through this entire instruction manual thoroughly before attempting to install this part. Image are for illustration purposes and may vary from your vehicle. Installation will remain the same.

! WARNING

Serious injury can occur when working on vehicles alone.

When possible, work with another person to reduce risk of injury from strain or other dangers that can occur when working alone.

! WARNING

The weight limit for these steps is 445lbs. Do not exceed this weight limit.


Exceeding this weight limit can cause damage or personal injury.



For Technical Support / Warranty Information please call 1-800-776-0767
Smittybilt, 1017 W. 600 N. STE 4, Ogden, UT 84404

Box Contents & Product Safety


EXJ184-TX Box Contents



ID	Part Description	QTY
1	Driver Side Angular Drop Step	1
2	Passenger Side Angular Drop Step	1
3	M8-1.25x35mm Hex Head Bolt	6
4	M8 Flat Washer	6

ID	Part Description	QTY
5	M8 Split Lock Washer	6
	M6-1.0x25mm Hex Head Bolt	12
	M6 Flat Washer	24
	M6 Nylock Nut	12

Installation Instructions: Jeep Gladiator® Angular Drop



Step 1:


If your JT® currently has running boards, remove them prior to proceeding.

Remove steps and hardware from the box. Confirm you have all the components needed for installation. Then, raise the **Driver Side Angular Drop Step** into place starting with the middle bracket loosely install using (1) **M8-1.25x35mm Bolt**, (1) **M8 Flat Washer**, and (1) **M8 Split Lock Washer** in the preexisting threaded hole. Then, install (2) **M6-1.0x25mm Bolts**, (4) **M6 Flat Washers**, and (2) **M6 Nylock Nuts** into the existing holes in the pinch weld as shown.



For Technical Support / Warranty Information please call 1-800-776-0767
Smittybilt, 1017 W. 600 N. STE 4, Ogden, UT 84404

Installation Instructions: Jeep JT® Angular Drop Steps



Step 2:

Repeat the process in the **Step 1** for the front and rear mounts on the **Driver Side Angular Drop Step**.



Step 3:

Confirm you are happy with the fitment and placement of the step. Then torque all **(6) M6 & M8 Bolts** to spec using the guide on **Page 6**.



Step 4:

Repeat **Steps 1-3** for the **Passenger Side Angular Drop Steps**.



For Technical Support / Warranty Information please call 1-800-776-0767
Smittybilt, 1017 W. 600 N. STE 4, Ogden, UT 84404

Installation Instructions: Jeep JT® Angular Drop Steps



Step 5:

Installation is now complete.





For Technical Support / Warranty Information please call 1-800-776-0767
Smittybilt, 1017 W. 600 N. STE 4, Ogden, UT 84404

Bolt Torque Specifications

Use this only as a guide for hardware without a called out torque specification in the instruction manual.

Bolt Torque and ID						
Decimal System			Metric System			
<i>All Torques in Ft. Lbs. Maximums</i>						
Bolt Size	Grade 5	Grade 8	Bolt Size	Class 9.8	Class 10.9	Class 12.9
5/16	15	20	M6	5	9	12
3/8	30	45	M8	18	23	27
7/16	45	60	M10	32	45	50
1/2	65	90	M12	55	75	90
9/16	95	130	M14	85	120	145
5/8	135	175	M16	130	165	210
3/4	185	280	M18	170	240	290



G= Grade (Bolt Strength)
 D= Nominal Diameter (Inches)
 T= Thread Count (Threads per Inch)
 L= Length (Inches)
 X= Description (Hex Head Cap Screw)

P= Property Class (Bolt Strength)
 D= Nominal Diameter (Millimeters)
 T= Thread Pitch (Thread Width, mm)
 L= Length (Millimeters)
 X= Description (Hex Head Cap Screw)



For Technical Support / Warranty Information please call 1-800-776-0767
 Smittybilt, 1017 W. 600 N. STE 4, Ogden, UT 84404

Notes and Disclaimers

Product cleaning and maintenance instructions

Stainless Steel Finish – Aluminum polish may be used to polish small scratches and scuffs on the finish. Mild soap, window or glass cleaner may be used to clean the finish. Dual state powder coat finish – Mild soap, window or glass cleaner may be used to clean the finish. In order to protect the finish, you may wax your product on a regular basis with pure carnauba automotive wax. Do not use any types of soap, polish or wax that contains abrasive that could damage the finish. Textured coated finishes should be cleaned with a mild soap on a damp sponge. Do not apply polish or wax that requires to be removed by means of buffing. This type of wax is commonly used at car wash facilities. Chrome Finish – Mild soap, window or glass cleaner may be used to clean the finish. In order to protect the finish, you should wax your product on a regular basis with pure carnauba automotive wax. Do not use any types of soap, polish or wax that contains abrasive that could damage the finish.

SMITTYBILT ADVANTAGE WARRANTY

LIMITED-LIFETIME WARRANTY FOR STRUCTURAL COMPONENTS

5-YEAR FINISH WARRANTY

Smittybilt Automotive Products, LLC (SAP) warrants to the original purchaser that (a) the physical components (e.g., metal components, welds, etc.) of any SAP **Jeep Gladiator® Angular Drop Steps** will be free of defects in material and workmanship for the lifetime of the product from the date of purchase of the Angular Drop Steps, and (b) the finish will be free of defects in material and workmanship for a period of 5-years from the original date of purchase. This warranty applies only to the original purchaser of the Angular Drop Steps and is non-transferable. To obtain any warranty service, you must provide SAP with a proof of purchase and date of purchase that is acceptable to SAP, such as a copy of your purchase receipt.

This warranty does not cover labor of part replacement of the Angular Drop Steps. SAP will, at its sole discretion, provide replacement part(s) for a defective Angular Drop Step or component, provided this is done within the warranty period. To request assistance under warranty, one must call or email using the phone number or email at the bottom of this page. This warranty does not apply (1) wearable components; or (2) if the Angular Drop Step(s) has/have been damaged, including, but not limited to: abuse, misuse, collision, modification, misapplication, improper installation, or improper service. This warranty is void if any SAP serial number has been removed or defaced; or if the Angular Drop Steps are used for any commercial, industrial, or rental applications. This warranty only applies to Angular Drop Steps bought, sold, and used within the United States or Canada unless otherwise specifically agreed in writing by SAP.

THE WARRANTY SET FORTH ABOVE IS THE ONLY WARRANTY. THERE ARE NO OTHER WARRANTIES, EXPRESSED OR IMPLIED, INCLUDING BUT NOT LIMITED TO IMPLIED WARRANTIES OF MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE. ANY IMPLIED WARRANTY WHICH BY LAW MAY NOT BE EXCLUDED IS LIMITED TO A DURATION OF ONE (1) YEAR FROM THE DATE OF ORIGINAL RETAIL PURCHASE OF THE PRODUCT. No SAP dealer, agent, or employee is authorized to make any modification, extension or addition to this warranty. SAP SHALL NOT BE LIABLE FOR SPECIAL, INDIRECT, INCIDENTAL OR CONSEQUENTIAL DAMAGES (INCLUDING, BUT NOT LIMITED TO, LOST PROFITS, DOWN TIME OR LOSS OF USE) UNDER ANY LEGAL THEORY, EVEN IF SAP WAS ADVISED OF THE POSSIBILITY OF SUCH DAMAGES. Some states do not allow the exclusion of implied warranties or the exclusion or limitation of liability for incidental or consequential damages, or limitations on how long an implied warranty lasts, so the above limitation or exclusion may not apply to you. This Warranty gives you specific legal rights. You may also have other rights that vary from state to state. SAP reserves the right to change product design without notice. In situations in which SAP has changed a product design, SAP shall have no obligation to upgrade or otherwise modify previously manufactured products. For warranty inquiries contact SAP at:

Smittybilt Automotive Products, LLC

Customer Service Department

Call 1-800-776-0767 or Email info@smittybilt.com



WARNING: Cancer and Reproductive Harm
www.P65Warnings.ca.gov



For Technical Support / Warranty Information please call 1-800-776-0767
Smittybilt, 1017 W. 600 N. STE 4, Ogden, UT 84404